



## MSC09041 Headlight Adapter Installation Procedure



**Figure 1.** Ford F150 Headlight Adapter Connections G10811

This installation Procedure is for 2012 & Newer Ford F150 trucks equipped with HID headlights.

1. Disconnect OEM Headlight Connector Plug (A) from the back of the vehicle headlight.
2. Connect end (B) of Headlight Adapter into the back of the vehicle headlight.
3. Connect end (C) of Headlight Adapter into the plow wiring harness.
4. Connect the Black Rubber Female Socket of the plow wiring harness into Headlight Adapter end (D).
5. Connect Headlight Adapter end (E) into OEM Headlight Connector Plug (A).
6. Connect Headlight Adapter end (F) to negative battery terminal.
7. Connect Headlight Adapter end (G) with fuse holder to positive battery terminal.
8. Repeat Steps 1 through 5 for the opposite side headlight.



**Figure 2.** Vehicle Option Connector

G10202

9. Locate vehicle option connector. Align the connector so that the wire colors are positioned to match the vehicle it is installed on. This is illustrated in Figure 2.

# 13-Pin Headlight Adapter Kit Ford HID Bulb MSC09041





Figure 1. Headlight Adapter Kit MSC09041